
Technical Publications

An Operator's Manual is shipped with this engine for customer use. Additional technical publications are available for these engines and can be purchased by using the publications ordering information located at the end of the Introduction.

The additional publications are strongly recommended for the customer who performs his own maintenance and service on Navistar, Inc. manufactured engines.

It is the policy of Navistar, Inc. to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to make such changes on products sold previously.

**INTERNATIONAL®
DT 466
United States Certified On-Highway
DIESEL ENGINES**
Equipped With
**International® Diamond Logic®
Engine Control Module**
For
**2001 Through 2003 Model Year
Truck and Derivative Vehicle Applications**

**Engine Operation
And Maintenance Manual**

Form No. 1 171 753 R4

Preview Only

© 2009 Navistar, Inc.

Preview Only

Scheduled (Normal) Maintenance Will

"Protect Your Investment"

Through Increased Equipment Reliability And Availability.

Normal maintenance is necessary to protect the long life built into your vehicle engine. Navistar, Inc. has designed a program to assist you in restricting delays and keep costly repairs to a minimum. This program consists of normal maintenance, scheduled lubrication intervals, adjustments and inspections. This program, when used, will result in reduced "down-time" and minimum repairs. The systematic procedure of lubrication, adjustments and inspection is outlined in the **MAINTENANCE INSTRUCTIONS** Section of this manual.

Instructions for operation, instrumentation, specifications, maintenance, records and troubleshooting are covered by this manual. The instructions are divided into sections to simplify reference to the most important information. The manual must be read completely prior to operating the engine to gain full knowledge of the engine and its correct normal maintenance and operation.

Preview Only

Preview Only

TABLE OF CONTENTS

INTRODUCTION

To The Operator.....	1
Safety Precautions.....	1
Publications Ordering Information.....	4

SECTION 1 – GENERAL INFORMATION

Component Location (Front View).....	5
Component Location (Left Side View).....	6
Component Location (Rear View).....	7
Component Location (Right Side View).....	8
Introduction:.....	9
DT 466 On-Highway Diesel Engine.....	9
Engine Identification:.....	9
DT 466 Series Diesel Engine Serial Number Locations.....	9
Explanation Of The Serial Number.....	11
Engine and Accessory Nameplates Locations.....	12
Turbocharger Identification (Non Wastegate Version).....	14
Turbocharger Identification (Wastegate Version).....	15

SECTION 2 – ENGINE SYSTEMS

General Features.....	17
Chassis Mounted Air-to-Air Cooler.....	18

SECTION 3 – WARRANTY INFORMATION

Emission Control Systems Maintenance And Limited Warranty.....	19
Federal Emission System Limited Warranty.....	19

TABLE OF CONTENTS

California Emission System Limited Warranty.....	20
Navistar Emission Limited Warranty Coverage.....	21
The Emission Limited Warranty Does Not Cover.....	23

SECTION 4 – INSTRUMENTS AND INDICATORS

Instrument Panel	25
Engine Diagnostics Lights	25
Water Temperature Gauge	26
Oil Pressure Gauge	27
Oil Temperature Gauge	28
Change Engine Oil Message	28
Air Cleaner Restriction Indicator	29
Air Restriction Indicator Test.....	30

SECTION 5 – OPERATION

Before Starting the Engine	31
Precautions.....	31
Engine Starting.....	32
Starting The Engine	33
Starting The Engine Above -12 °C (10 °F) Ambient Temperature.....	33
Starting The Engine Below -12 °C (10 °F) Ambient Temperature With Optional Ether Injector... ..	35
Emergency Starting	38
Operating Instructions	39
Cold Weather Operation.....	39
Hot Weather Operation.....	40
Extended Idling Periods.....	40
CAP Shutoff.....	41
Engine Shutdown.....	41

TABLE OF CONTENTS

Automatic Engine Idle Shutdown.....	41
Shutdown Warning Light Or Audible Alarm.....	42
Parking.....	42
Road Operation.....	43
Downhill Operation.....	43
Idle Speeds.....	43

SECTION 6 – SPECIFICATIONS AND CAPACITIES

Fuel Requirements.....	47
Recommended Fuel For Navistar Diesels.....	47
Advisory.....	47
Diesel Fuel/Gasoline Blends	48
Hazards Of Fire And Explosion.....	48
Engine Performance Problems.....	49
Cooling System.....	49
Requirements.....	49
Rotella Extended Life Coolant (Red In Color).....	50
Cooling System Specifications.....	50
Maintaining Required Inhibitor Concentration (For Extended Life Coolant) {Red In Color}.....	50
Coolant Testing For Inhibitor Concentration – (For Extended Life {Red} Coolants).....	52
Cooling System Requirements – (For Conventional Coolant (Green In Color).....	52
Ethylene Glycol Antifreeze.....	52
Propylene Glycol Antifreeze.....	53
Maintaining Required Conditioner Concentration (For Conventional Antifreeze {Green In Color}).....	53
Coolant Filter/Conditioner (If Equipped).....	54
Coolant Testing For Conditioner Concentration – (For Conventional {Green} Coolants).....	55
Cleaning The Cooling System.....	57
Corrosion Prevention.....	57

TABLE OF CONTENTS

Radiator Fins.....	58
Coolant Hoses.....	59
Thermostat.....	59
Contamination Of Coolant.....	59
Engine Lubrication Requirements.....	59
Oil Quality.....	59
Oil Viscosity.....	60
Oil Change Interval.....	61
Identification Symbol.....	62
Crankcase Oil Specifications.....	63
DT 466 Series Diesel Engine Crankcase Refill Capacities For Unit Without Front Drive/Steering Axle.....	63
DT 466 Series Diesel Engine Crankcase Refill Capacities For Unit With Front Drive/Steering Axle AND SHORT FILTER.....	63
Checking Engine Oil Level.....	63

SECTION 7 – MAINTENANCE INSTRUCTIONS

General.....	65
Maintenance Operations.....	65
Maintenance Operations — 1 through 6 Daily Maintenance Schedule.....	71
OPERATION 1 – Check Oil Level (Daily).....	71
OPERATION 2 — Check Coolant Level (Daily).....	72
OPERATION 3 — Water Separator, Fuel System - If Equipped (Daily).....	72
OPERATION 4 — Inspect Air-to-Air Cooler (Daily).....	73
OPERATION 5 — Inspect for External Leakage (Daily).....	73
OPERATION 6 — Inspect Air Cleaner Restriction Indicator (Daily).....	74
Maintenance Operations – 7 through 10 Inspection Interval: Every 24,100 km, (15,000 miles), 550 hours, 6 months or 2100 Gallons of Fuel; Whichever Occurs First.....	75
OPERATION 7 — Inspect Belt.....	75

TABLE OF CONTENTS

OPERATION 8 — Change Engine Oil And Oil Filter.....	76
Reset Change Oil Message.....	77
OPERATION 9 — Check Coolant SCA Concentration.....	78
OPERATION 10 — Inspect Air Intake Piping.....	79
Maintenance Operations – 11 thru 12 Inspection Interval: Every 48,300 km (30,000 miles), 1,100 hours, 12 months or 4200 Gallons of Fuel; Whichever Occurs First.....	80
OPERATION 11 — Measure Air Intake Restriction.....	80
Optional Dual Element Cleaner.....	80
OPERATION 12 — Change Fuel Filter And Strainer Assembly.....	83
Bleeding Air From Fuel System.....	86
Maintenance Operation - 13 Replacement Intervals Depend On Type Of Coolant Used. See Section 7, Table 2 For Replacement Interval. Coolant Types Are Extended Life (Red In Color) And Conventional (Green In Color).....	87
Change Coolant Filter (If Equipped).....	87
Maintenance Operation — 14 Inspection Interval: Every 24 Months.....	88
Pressurize Induction System.....	88
Maintenance Operation — 15 Inspection Interval: Every 193,100 Km (120,000 Miles), 5,000 Hours; Whichever Occurs First.....	88
Inspection Vibration Damper.....	88
Maintenance Operation — 16 Inspection Interval: Every 193,100 Km (120,000 Miles), 5,000 Hours; Whichever Occurs First.....	89
Adjust Valve Lash.....	89
Maintenance Operations 17 And 18 Inspection Interval: Every 290,000 To 322,000 Km (180,000 to 200,000 miles), 6,700 To 7,500 Hours; Whichever Occurs First.....	89
OPERATION 17 — Measure Crankcase Pressure.....	89
OPERATION 18 — Inspect Turbocharger.....	89
Maintenance Operation — 19 Inspection Interval: Annually.....	90
Inspect Electrical System.....	90
Maintenance Operation — 20 Inspection Interval: Every 322,000 Km (200,000 Miles), 3,800 Hours Or 2 Years; Whichever Occurs First.....	91

TABLE OF CONTENTS

Service Cooling System.....	.91
For School Bus.....	.92
Clean Cooling System.....	.93
Maintenance Operation — 21 Inspection Interval: Every 500,000 Km (300,000 Miles), 12,000 Hours Or 5 Years; Which Ever Occurs First.....	.93
Check Extended Life Coolant Inhibitor Concentration.....	.93
 SECTION 8 – SERVICE RECORDS	
Emission Maintenance Service Record.....	.95
 SECTION 9 – DAILY MAINTENANCE REPORT	
Description.....	.99

Preview Only